

Fresh Air Scoop Installation Manual



The **Jass Performance Fresh Air Scoop** is plug and play solution, which should considerably enhance the open air experience in your convertible by:

- Introduces some more intense contact with the outer world in the form of smells
- Directs good amount of fresh air to the footwell, where the OEM fresh air fan is challenged to deal with the low pressure with open top and higher speeds
- Reduces the low pressure and with it the strong draft from the behind the passengers

Installation steps:

1. Unclip the mirror base cover, by carefully lifting it up with a pair of flat screwdrivers.
2. Remove the interior mirror by unscrewing the two bolts holding it to the top.
3. Mount the top bracket as shown in the picture above – the side receiving cut out should be offset to the car front. It installs underneath the base of the interior mirror and the mirror bolts back in place.
4. Attach the Air Scoop by positioning and clicking its sides to the received bracket of the mirror.



Now take a break and enjoy the new vision of your roadster.

With regards, Jass Performance!